




Showing position of cover and motor when closing machine.

WE sewing machine manual 1920
H5527-10